

## Battery Box Installation Instructions

1. Remove the cover of the battery box by loosening the four plastic corner screws (the plastic screws will remain in the cover).
2. Mount the battery box to a flat surface using four screws or bolts inserted through the same holes that the four plastic corner screws go in. You may have to punch holes through a thin layer of plastic at the bottom of these holes.
3. Connect the white wire from the battery box to the negative wire on the outdoor wireless intercom. Connect the red wire of the callbox to the positive wire of the intercom. You will likely need to use additional two-conductor 24 gauge wire or larger to reach the intercom from the mounting location since the wire provided is only about 10 inches long.
4. Install 6 good-quality D-cell batteries ensuring to observe the proper polarity.
5. Replace the cover. The cover is keyed and will only fit on the box in one direction so line up the keys with the slots when replacing the cover.

